

Pipe Support Spacing Table Academic PDF

Pipe support spacing table is an essential tool in the field of mechanical and structural engineering, especially when designing piping systems that are safe, efficient, and compliant with industry standards. Proper support placement ensures that pipes are adequately supported to prevent sagging, vibrations, or failure due to thermal expansion, pressure loads, and other operational stresses. In this comprehensive guide, we will explore the significance of pipe support spacing tables, how they are structured, factors influencing support spacing, and practical applications to ensure optimal piping system design.

Understanding Pipe Support Spacing Table

A **pipe support spacing table** is a reference chart that provides recommended distances between supports along a pipe run, based on various factors such as pipe material, diameter, wall thickness, and the type of support used. These tables are vital for engineers and designers to determine the appropriate support locations, ensuring the pipe's structural integrity and operational safety.

Importance of Proper Support Spacing

Proper support spacing maintains the pipe's alignment and prevents excessive deflection or deformation. It also reduces stress concentrations that could lead to fatigue or failure over time. Key benefits include:

- Minimizing pipe sagging and vibration
- Reducing thermal expansion stresses
- Preventing damage to pipe insulation and cladding
- Ensuring compliance with codes and standards such as ASME B31.3, API, and others

Components of a Pipe Support Spacing Table

A typical pipe support spacing table contains several columns and rows, each representing specific parameters:

Common Parameters Included

- **Pipe Diameter (D):** Usually expressed in inches or millimeters, indicating the size of the pipe.
- **Pipe Material:** Steel, copper, plastic, or other materials, affecting support requirements.

- **Wall Thickness:** Influences the pipe's strength and support needs.
- **Support Type:** Fixed supports, hangers, clamps, or special supports like guides or rollers.
- **Support Spacing (L):** The recommended distance between supports.
- **Operating Conditions:** Temperature, pressure, and thermal expansion considerations.

These tables are often segmented based on pipe diameter ranges, material types, and support types for ease of reference.

Factors Influencing Pipe Support Spacing

While tables provide general guidelines, several factors can influence the support spacing decisions for specific applications:

1. Pipe Diameter and Wall Thickness

Larger diameter pipes with thicker walls require supports at shorter intervals to prevent excessive sagging and deformation.

2. Pipe Material

Materials like steel can handle higher stresses, allowing for longer support spans, whereas plastics or brittle materials need closer support spacing.

3. Operating Temperature and Pressure

Higher temperatures induce thermal expansion, necessitating closer supports or expansion loops to accommodate movement.

4. Type of Support Used

Rigid supports such as anchors or guides limit movement, while flexible supports like hangers or spring supports allow for thermal expansion, affecting spacing.

5. Environmental Conditions

External factors like vibration, seismic activity, or corrosive environments may require additional supports or specialized support types.

6. Industry Standards and Codes

Codes such as ASME B31.3, BS EN 13480, or API 650 provide specific guidelines that must be

adhered to during support placement.

Typical Support Spacing Guidelines

While specific tables vary, some standard guidelines are widely accepted in the industry:

Steel Pipes

- For pipes up to 2 inches in diameter: support every 5-6 feet.
- For pipes 2-6 inches: support every 8-10 feet.
- For pipes above 6 inches: support every 10-12 feet.

Plastic Pipes

- Support every 3-4 feet for small diameters.
- Support spacing increases with pipe diameter and wall thickness.

Note that these are general approximations; always refer to specific tables for precise values.

Creating and Using a Pipe Support Spacing Table

To develop an effective support spacing table tailored to your project, follow these steps:

Step 1: Identify Pipe Parameters

Gather details on pipe diameter, material, wall thickness, and operating conditions.

Step 2: Consult Industry Standards

Refer to relevant standards such as ASME B31.3 or manufacturer recommendations.

Step 3: Determine Support Types

Decide on the types of supports to be used?rigid, flexible, spring supports, etc.

Step 4: Calculate Support Spacing

Use existing tables as a reference or perform calculations considering deflection limits, thermal movement, and load conditions.

Step 5: Validate Design

Ensure the proposed support spacing complies with safety margins and operational requirements.

Practical Applications of Pipe Support Spacing Tables

Accurate support spacing tables are applied across various phases of piping system design and installation:

- **Design Phase:** Engineers determine support locations to optimize pipe layout and minimize costs.
- **Construction Phase:** Contractors use tables to install supports correctly and adhere to safety standards.
- **Maintenance and Inspection:** Support spacing guides help in identifying potential areas of stress or wear.

Additionally, support spacing tables are incorporated into CAD drawings, piping isometric drawings, and maintenance manuals to ensure consistency and compliance.

Conclusion

In summary, a **pipe support spacing table** is a fundamental resource that facilitates the safe and efficient design of piping systems. Proper support placement based on these tables prevents issues related to pipe sagging, vibration, thermal expansion, and structural failure. When designing or maintaining piping systems, always consult the most recent industry standards, consider all influencing factors, and tailor support spacing to specific operational conditions. By doing so, engineers and technicians can ensure the longevity, safety, and reliability of piping infrastructure across various industries.

Additional Tips for Using Pipe Support Spacing Tables

- Always verify support spacing with actual load calculations when dealing with special conditions.
- Consider thermal expansion allowances, especially in long pipe runs.
- Use flexible supports where movement is anticipated.
- Regularly inspect supports for corrosion, wear, or displacement.
- Update support spacing plans based on operational feedback and maintenance data.

By adhering to these practices and utilizing comprehensive support spacing tables, you can ensure your piping systems are robust, compliant, and built for durability.

Pipe support spacing table: Ensuring Structural Integrity and Efficiency in Piping Systems

In the realm of industrial piping, mechanical engineering, and infrastructure design, the importance of proper pipe support spacing cannot be overstated. A pipe support spacing table serves as an essential reference tool, guiding engineers and installers to establish optimal distances between supports that guarantee safety, durability, and operational efficiency. Proper support spacing not only prevents structural failure but also mitigates issues such as excessive pipe deflection, vibrations, and thermal expansion stresses. This article offers a comprehensive exploration of pipe support spacing tables, delving into their significance, underlying principles, factors influencing support distances, and practical applications across various industries.

Understanding Pipe Support and Its Significance

What Are Pipe Supports?

Pipe supports are structural devices used to hold piping systems in place, ensuring stability, alignment, and safety during operation. They are designed to bear the weight of the pipe, accommodate thermal movements, and reduce stresses that could lead to material fatigue or failure. Supports can vary from simple hangers and clamps to complex structural frames, depending on the pipe size, material, and purpose.

The Role of Pipe Support Spacing

The spacing of pipe supports directly impacts the pipe's performance and longevity. Properly spaced supports:

- Minimize pipe deflection under fluid pressure, weight, and thermal expansion.
- Prevent sagging or misalignment that can cause leaks or operational inefficiencies.
- Reduce stress concentrations that may lead to cracks or failures.
- Control vibration and noise, especially in high-flow systems.
- Facilitate safe and easy maintenance access.

Hence, a well-designed support system rooted in accurate spacing guidelines is fundamental for safe plant operations, cost-effective maintenance, and adherence to safety standards.

Fundamentals of Pipe Support Spacing Tables

What Is a Pipe Support Spacing Table?

A pipe support spacing table is a standardized or project-specific chart that specifies the maximum allowable distances between supports based on various parameters such as pipe size, material, insulation, and operating conditions. These tables are typically compiled from engineering codes, manufacturer recommendations, and practical experience.

Core Components of Support Spacing Tables

A typical support spacing table includes:

- Pipe Diameter (Nominal or Outside Diameter): Usually measured in inches or millimeters.
- Pipe Material: Steel, copper, PVC, or other materials, each with different stiffness and thermal properties.
- Pipe Thickness or Schedule: Thicker pipes may require different support spacing.
- Operational Temperature and Pressure: Elevated temperatures can cause expansion and require wider support spacing.
- Type of Support: Hangers, clamps, rollers, or adjustable supports.
- Support Spacing (Maximum Distance): Usually given in meters or feet, indicating the recommended maximum span between supports.

Some tables also provide additional notes or warnings about special conditions, such as high thermal loads, seismic zones, or vibration-prone environments.

Factors Influencing Pipe Support Spacing

The determination of appropriate support spacing is influenced by a range of technical parameters and operational considerations:

1. Pipe Diameter and Wall Thickness

- Larger diameter pipes tend to have higher bending moments and deflections, necessitating closer support spacing.
- Thicker walls increase rigidity, allowing for wider support spans.

2. Material Properties

- Steel pipes are stiffer compared to plastics or copper, permitting longer spans.
- Flexible materials may require closer supports to prevent excessive deflection.

3. Operating Temperature and Thermal Expansion

- Elevated temperatures increase thermal expansion, which can cause significant movement.
- Supports must accommodate these movements, often resulting in adjusted spacing or specialized supports (like sliding or expansion supports).

4. Fluid Pressure and Flow Rate

- High pressure or flow velocity can induce vibrations or pulsations.
- Supports may need to be more frequent to dampen vibrations.

5. Environmental Factors

- External factors such as seismic activity, wind loads, or corrosive environments influence support design and spacing.
- Supports in seismic zones or exposed to lateral forces require reinforced or more frequent supports.

6. Code and Standards Compliance

- Industry standards such as ASME B31.1, B31.3, OSHA regulations, and local building codes provide minimum support requirements.
- These standards often dictate maximum spans based on pipe size, material, and operating conditions.

Typical Support Spacing Guidelines Across Industries

While specific tables vary, industry standards provide general guidance:

1. Steel Pipes (Carbon or Stainless Steel)

| Pipe Diameter (inches) | Typical Support Spacing (feet) | Notes |

|-----|-----|-----|

| 1/2" ? 2" | 3 ? 4 | For standard operating conditions |

2" ? 6" 4 ? 6 Increased span for larger sizes
6" ? 12" 6 ? 8 For high-temperature or high-pressure systems
Above 12" 8 ? 12 Custom supports often required

Note: These are approximate values; always consult relevant standards.

2. Plastic and PVC Pipes

Pipe Diameter (mm) Support Spacing (meters) Notes
----- ----- -----
Up to 50 mm 1 ? 1.5 Flexible materials, less support required
50 ? 100 mm 1.5 ? 2 Consider thermal expansion and environmental factors
Above 100 mm 2 ? 3 Larger spans require specialized supports

3. Considerations for Thermal Expansion

- For systems with significant temperature fluctuations, supports are placed to allow free expansion or include expansion joints.
- Support spacing may be widened in such cases but must be balanced with stability needs.

Designing and Selecting Appropriate Pipe Support Spacing

Step-by-Step Approach

- Identify Pipe Parameters: Diameter, material, wall thickness, insulation, and operating conditions.
- Consult Industry Standards: Refer to applicable codes (e.g., ASME B31.3 for process piping, ASME B31.1 for power piping).
- Assess Environmental Factors: Temperature, seismic zones, wind loads, corrosive environments.
- Determine Support Type: Hangers, clamps, rollers, or specialized supports.
- Calculate Expected Deflections: Use structural analysis to ensure deflections stay within permissible limits.

- Select Support Spacing: Based on the above, choose support locations from the table, adjusting for specific project needs.
- Incorporate Flexibility and Expansion Provisions: To accommodate thermal movement, expansion loops, or sliding supports.
- Verify and Document: Ensure compliance with standards and document support locations and spacing.

Practical Applications and Case Studies

Industrial Plants and Refineries

In complex facilities such as refineries, support spacing tables are critical for large-diameter high-pressure pipes. For example, support spacing for a 12-inch carbon steel pipe operating at high temperature might be limited to 8 feet to prevent excessive deflection and stress.

HVAC Systems

Heating, ventilation, and air conditioning (HVAC) piping often involves smaller diameter plastic pipes. Support spacing can be wider?up to 3 meters?due to the flexibility of materials, but considerations for vibration and thermal movement still dictate support placement.

Water Transmission and Distribution

Municipal water systems employ support spacing tables aligned with standards like AWWA (American Water Works Association). These ensure pipelines maintain integrity over long distances, often requiring supports every 6?10 meters depending on pipe size and terrain.

Emerging Trends and Innovations

The evolution of support support spacing tables is driven by advances in materials science, structural analysis, and automation:

- Use of Advanced Materials: Composite supports or low-friction sliding supports allow for wider spans and better thermal movement accommodation.
- Computer-Aided Design (CAD): Precise modeling enables optimized support placement, reducing material costs and enhancing system performance.
- Standards Evolution: Updates to codes incorporate new research, leading to more flexible support spacing guidelines tailored to modern materials and operating conditions.
- Smart Supports: Integration of sensors to monitor support loads and deflections in real-time, enabling dynamic adjustments and predictive maintenance.

Conclusion

The pipe support spacing table is an indispensable tool in the design and maintenance of piping systems across industries. By providing clear guidelines grounded in engineering principles and standards, these tables help ensure that pipelines operate safely, efficiently, and sustainably. Proper support placement minimizes mechanical stresses, accommodates thermal and operational movements, and extends the lifespan of the piping infrastructure. As technology advances, support spacing tables are expected to become more refined, incorporating real-time data and adaptive supports to meet the evolving demands of modern industrial systems. For engineers, contractors, and plant operators alike, mastering the principles behind support spacing is crucial for building resilient and reliable piping networks that stand the test of time.

Question What is a pipe support spacing table and why is it important? A pipe support spacing table provides recommended distances between supports for different pipe sizes, materials, and operating conditions. It is essential for ensuring the structural integrity, safety, and longevity of piping systems by preventing excessive deflection, vibration, and stress. **Answer** How do I select the appropriate support spacing for a specific pipe size? To select the correct support spacing, refer to relevant industry standards or manufacturer tables that consider pipe diameter, material, weight, and the type of support. Always ensure the spacing complies with local codes and project specifications for optimal performance. Are pipe support spacing tables different for various pipe materials? Yes, support spacing tables vary depending on the pipe material (e.g., steel, PVC, copper) because different materials have different weight, flexibility, and thermal expansion properties. Always use material-specific tables for accurate support spacing recommendations. Can pipe support spacing tables be used for both horizontal and vertical piping systems? Support spacing tables are primarily designed for horizontal piping. For vertical systems, support requirements may differ due to gravity and load distribution, so additional guidelines or tables should be consulted for vertical piping support design. How often should pipe supports be inspected according to support spacing guidelines? Inspections should typically be conducted at regular intervals, such as annually or biannually, depending on the system's environment and usage. Proper support spacing ensures easier inspection and maintenance, but routine checks are essential for safety and system integrity. Where can I find standard pipe support spacing tables for my project? Standard pipe support spacing tables can be found in industry standards such as ASME B31.3, ASME B31.1, or manufacturer catalogs. Consulting these standards or working with engineering professionals ensures compliance with best practices and project requirements.

Related keywords: pipe support spacing, pipe support design, pipe support types, pipe support calculation, pipe hanger spacing, pipe support standards, pipe support materials, pipe support installation, pipe support guidelines, pipe support specifications

MAXIMUM ALLOWABLE SPAN FOR HDPE PIPE

Maximum allowable span for hdpe pipe is a critical consideration in the design, installation, and maintenance of high-density polyethylene (HDPE) piping systems. Properly determining the span ensures the structural integrity, longevity, and safety of the pipeline, whether it is used for water supply, sewage, gas, or industrial applications. HDPE pipes are renowned for their flexibility, durability, and resistance to corrosion, making them a popular choice across various industries. However, even with these advantageous properties, improper span lengths can lead to unwanted stress, deformation, or failure. Therefore, understanding the maximum allowable span for HDPE pipes is essential for engineers, contractors, and project managers to optimize pipe performance and compliance with relevant standards.

Understanding HDPE Pipe Characteristics and Their Impact on Span

HDPE pipes are manufactured through a process that results in a semi-rigid yet highly flexible pipe material. This flexibility allows the pipe to withstand ground movements and minor shifts without cracking or breaking. However, it also means that the pipe's unsupported span must be carefully controlled to prevent sagging, deformation, or excessive stress on the pipe walls.

The key characteristics influencing the maximum allowable span include:

- Pipe diameter
- Pipe wall thickness (DR ? Dimension Ratio)
- Pipe material and grade
- Installation environment and load conditions
- Support conditions and bedding

These factors collectively determine the maximum span length that the pipe can safely sustain without additional supports or anchors.

Standards and Guidelines Governing HDPE Pipe Spans

Several national and international standards provide guidelines for the permissible spans of HDPE pipes. These standards aim to ensure safety, durability, and performance across different applications.

ASTM International Standards

- ASTM F2164: "Standard Specification for Polyethylene (PE) Large Diameter Profile Wall and Solid Wall Pipe"
- ASTM D3035: "Standard Specification for Polyethylene (PE) Plastic Pipe (DR-PR) Based on Outside Diameter"

ISO Standards

- ISO 4437: "Polyethylene (PE) pipes and fittings for gas supply systems" ? includes guidelines for installation and support
- ISO 4427: "Polyethylene pipes for water supply" ? specifies installation requirements including span considerations

European Standards (EN)

- EN 12201: "Specifications for polyethylene pipes for water supply, drainage, and sewerage" ? addresses installation and support

Adherence to these standards helps ensure that HDPE piping systems are installed with appropriate spans that prevent structural issues and promote long-term performance.

Factors Influencing the Maximum Span for HDPE Pipes

Determining the maximum span involves analyzing various factors:

Pipe Diameter and Thickness

Larger diameter pipes generally require shorter spans due to increased bending moments and potential sagging. Similarly, thicker walls (lower DR ratios) provide greater stiffness, allowing for longer spans.

Load Conditions

- Static Loads: Soil weight, traffic loads, or attached equipment can exert stress on the pipe.
- Dynamic Loads: Vibrations, water hammer, or ground movement may impact span considerations.

Support Conditions and Bedding

Proper bedding and support reduce bending stresses. The type of bedding (e.g., compacted granular material, concrete cradle) influences the maximum allowable span.

Environmental Conditions

Exposure to temperature variations, UV radiation, or chemical environments can affect pipe flexibility and strength, thereby impacting span limits.

Typical Maximum Spans for HDPE Pipes

While actual spans depend on specific project conditions and standards, typical values derived from engineering practices and guidelines are as follows:

Based on Pipe Diameter and Wall Thickness

Pipe Diameter (mm)	Typical Max Span (m)	Notes
-----	-----	-----
63 - 160	1.5 - 3.0	Light loads, good bedding
200 - 400	3.0 - 6.0	Moderate loads, proper bedding essential
450 - 600	4.5 - 9.0	Heavy loads, reinforced bedding recommended
700 - 1000	6.0 - 12.0	Industrial applications, support structures necessary

Note: These values are approximate and should always be verified against relevant standards and site-specific conditions.

Design Considerations for Spanning HDPE Pipes

Proper design is essential to optimize span lengths while maintaining safety and durability.

Calculating Bending Stress

The bending stress in a pipe supported at regular intervals can be estimated using the formula:

$$\sigma_b = \frac{M \times c}{I}$$

Where:

- σ_b is the bending stress
- M is the bending moment
- c is the distance from neutral axis to outer fiber
- I is the moment of inertia

Design should ensure that the bending stress remains below the pipe's allowable stress limit.

Support Spacing and Bedding Design

- Use bedding materials with sufficient compaction to distribute loads evenly.
- Incorporate support intervals based on pipe size and load conditions.
- For large diameters or high loads, consider using concrete cradles or additional supports.

Allowances for Thermal Expansion

HDPE pipes expand and contract with temperature changes. Spans should factor in thermal movement to prevent buckling or undue stress.

Installation Best Practices to Maximize Pipe Longevity

Proper installation practices are vital for maintaining correct span lengths and ensuring the pipe's structural integrity.

- **Site Assessment:** Evaluate soil conditions, load factors, and environmental influences.
- **Support Spacing:** Follow manufacturer recommendations and standards for support intervals.
- **Bedding Preparation:** Use suitable bedding materials and ensure proper compaction.
- **Handling and Placement:** Avoid excessive bending or dragging during installation.
- **Testing and Inspection:** Conduct pressure tests and visual inspections before backfilling.

Adhering to these practices helps prevent issues related to overextended spans, such as sagging, deformation, or early failure.

Conclusion: Ensuring Optimal Pipe Performance Through Proper Span Management

The maximum allowable span for HDPE pipe is a fundamental parameter that directly influences the durability, safety, and efficiency of piping systems. While the typical spans vary based on pipe size, material grade, support conditions, and environmental factors, industry standards and engineering best practices provide clear guidance to determine safe support intervals. Proper design,

installation, and support strategies?rooted in understanding the pipe?s characteristics and the project?s specific demands?are essential for achieving a reliable and long-lasting piping system.

In summary:

- Always reference relevant standards such as ASTM, ISO, and EN for specific span guidelines.
- Consider all load and environmental factors during design.
- Use appropriate bedding and support systems.
- Regularly inspect and maintain installed pipelines to detect and address potential issues early.

By carefully managing the maximum span for HDPE pipes, engineers and contractors can ensure that their systems operate effectively for decades, providing safe and sustainable infrastructure solutions.

Maximum Allowable Span for HDPE Pipe: An Expert Review

High-Density Polyethylene (HDPE) pipes have become the material of choice for diverse applications ranging from water supply and sewage systems to industrial and mining operations. Their durability, flexibility, and chemical resistance make them ideal for various demanding environments. One critical aspect that engineers, contractors, and project planners must consider when designing and installing HDPE piping systems is the maximum allowable span?the distance between supports or anchors that ensures the pipe's structural integrity, flow efficiency, and longevity.

Understanding the maximum allowable span is essential to prevent issues such as sagging, undue stress, premature failure, or flow restrictions. This article delves deeply into what influences the span limits of HDPE pipes, providing comprehensive guidelines, engineering considerations, and practical insights to help professionals optimize their piping systems.

Understanding HDPE Pipe and Its Structural Characteristics

Before exploring span limitations, it?s important to understand the fundamental properties of HDPE pipes that influence their support requirements.

What Is HDPE Pipe?

HDPE pipes are made from high-density polyethylene resin, characterized by high tensile strength, excellent chemical resistance, and remarkable flexibility. Their seamless, corrosion-resistant construction makes them suitable for underground and pressurized systems.

Key Properties Affecting Span

- **Flexibility:** HDPE pipes can bend without breaking, reducing the need for extensive supports in some cases.
- **Tensile Strength:** While strong under tension, their ability to withstand bending stresses depends on diameter and wall thickness.
- **Elasticity:** HDPE's elastic behavior allows it to deform under load and return to shape, but excessive bending or unsupported spans can lead to deformation.
- **Wall Thickness (DR Series):** The dimension ratio (DR) impacts stiffness; higher DR (thinner walls) means more flexibility, influencing span limits.

Factors Influencing the Maximum Allowable Span

The maximum span of an HDPE pipe isn't arbitrary; it's governed by multiple interconnected factors that must be carefully evaluated during design. These include:

- **Pipe Diameter and Wall Thickness**
 - **Diameter:** Larger diameters tend to be more susceptible to sagging unless supported adequately because of increased weight and bending moment.
 - **Wall Thickness (or SDR - Standard Dimension Ratio):** Thicker walls (lower SDR) provide greater stiffness, allowing longer spans without support.

- **Pipe Material and Grade**

Different HDPE grades (e.g., PE80, PE100) have varying mechanical properties, especially tensile strength and stiffness. Higher grades generally permit longer unsupported spans due to improved load-bearing capacity.

- **Installation Environment**

- **Buried vs. Above Ground:** Buried pipes are supported by the surrounding soil, reducing the need for internal supports. Above-ground pipes require careful support design.
- **Soil Conditions:** Stable, dense soils provide better support; loose or variable soils may necessitate shorter spans.

- Temperature: Elevated temperatures can soften HDPE, reducing its load-carrying capacity and possibly decreasing maximum span.
- Internal Pressure and Flow Dynamics
 - Internal Pressure: Higher internal pressures induce hoop and longitudinal stresses that influence permissible span.
 - Flow Rate and Velocity: Rapid flow or high velocities can cause vibrations or pressure surges that impact support requirements.
- Support and Anchorage Design

Properly designed supports, anchors, and restraints can significantly extend the feasible span, especially when considering dynamic loads and thermal expansion.

Standards and Guidelines for HDPE Pipe Spans

Multiple standards and industry guidelines provide recommendations for maximum spans, but these are often conservative estimates to ensure safety and longevity.

International Standards Overview

- ISO 16133: Specifies testing and design considerations but offers limited direct span parameters.
- ASTM D3035: Provides properties and installation guidelines that impact span considerations.
- AWWA C906: Offers design and installation practices specifically for HDPE pressure pipes.
- DIN 8074/8075 and BS EN 12201: European standards with recommendations on support intervals based on pipe size and application.

Industry-Recommended Spans

Based on accumulated industry experience and standards, typical maximum unsupported spans are:

Pipe Diameter (mm)	Typical Maximum Span (m)	Notes
-----	-----	-----

- | Up to 63 mm | 3 to 4 | Small pipes, often supported at shorter intervals |
- | 75 mm ? 160 mm | 4 to 6 | Moderate support intervals |
- | 200 mm ? 315 mm | 6 to 9 | Longer spans permissible with proper supports |
- | 355 mm ? 630 mm | 9 to 12 | Larger diameters, support design becomes critical |
- | > 630 mm | 12+ | Requires detailed engineering analysis |

Note: These are general guidelines; actual spans depend on the factors outlined earlier.

Engineering Calculations and Design Considerations

Designing for maximum span involves detailed calculations considering load, pipe stiffness, and support conditions.

- Bending Stress and Deflection

The primary concern when considering unsupported spans is the deflection under the pipe's own weight and operational loads.

- Maximum Allowable Deflection: Often limited to 5% of the pipe diameter to prevent excessive sagging.

- Calculation Approach:

\[

$$\Delta = \frac{5wL^4}{384EI}$$

\]

Where:

- Δ : allowable deflection
- w : load per unit length (self-weight + additional loads)
- L : span length
- E : modulus of elasticity

- I : moment of inertia of the pipe cross-section

By rearranging, engineers determine the maximum span L that keeps deflection within limits.

- Load Factors and Support Conditions

- Point Supports vs. Continuous Supports: Continuous supports distribute load more evenly, allowing longer spans.

- Support Type: Rigid supports (e.g., concrete blocks) vs. flexible supports (e.g., soil beds) influence allowable span.

- Thermal Expansion and Contraction

HDPE's thermal movement can cause stress if spans are too long without allowances, leading to deformation or failure.

- Expansion Coefficient: Approximately $(1.5 \times 10^{-4}) / ^\circ\text{C}$.
- Design Solution: Incorporate expansion joints or support points to accommodate movement.

- Soil and Environmental Conditions

In buried applications, the surrounding soil provides support. However:

- Loose or Wet Soils: Require shorter spans or additional bedding.
- Rocky or Firm Soils: Permit longer unsupported spans.

Practical Guidelines for Installing HDPE Pipes with Optimal Spans

While theoretical calculations provide a foundation, practical experience and field conditions often dictate support intervals.

General Best Practices

- Support at Regular Intervals: Typically every 1.5 to 3 meters for small to medium pipes.

- Specialized Supports for Large Diameter Pipes: For pipes over 315 mm, supports are often spaced every 6 to 12 meters, depending on load and environment.
- Use of Cradles and Bedding: Proper bedding reduces stress and distributes loads evenly.
- Thermal Considerations: In regions with significant temperature variation, supports should accommodate expansion.
- Monitoring and Inspection: Periodic checks for sagging or deformation, especially in long spans.

Case Studies and Real-World Examples

Case Study 1: Urban Water Pipeline

A city planning to install a 200 mm HDPE water pipeline above ground opted for supports every 8 meters. The supports consisted of concrete cradles designed to withstand soil movement and temperature fluctuations. The design adhered to the maximum span guidelines, ensuring minimal deflection and no flow issues.

Case Study 2: Industrial Drainage System

An industrial facility used 315 mm HDPE pipes for drainage, supported every 10 meters with heavy-duty supports. The design accounted for high flow velocities and potential thermal expansion. The supports were engineered to accommodate movement, allowing longer spans without compromising system integrity.

Conclusion: Striking the Balance Between Support and Flexibility

The maximum allowable span for HDPE pipes is not a fixed number but a carefully determined parameter influenced by multiple factors: diameter, wall thickness, material grade, environmental conditions, and installation practices. While industry guidelines offer a valuable starting point, the optimal design must incorporate detailed engineering calculations, site-specific conditions, and adherence to relevant standards.

In practice, well-planned support intervals ensure the longevity and reliable performance of HDPE piping systems, minimizing maintenance costs and preventing failures. As HDPE pipe technology advances and standards evolve, engineers must stay informed about best practices and innovative solutions to maximize span efficiency without compromising safety or functionality.

By understanding and applying the principles outlined in this review, professionals can design piping systems that leverage the full benefits of HDPE's flexibility and durability while respecting the critical limits of unsupported spans.

In summary:

- Support intervals for HDPE pipes vary based on diameter, wall thickness, and environment.
- Industry standards recommend spans ranging from 3 meters for small pipes up to over 12 meters for large ones, with detailed engineering analysis to confirm.
- Proper support design, environmental considerations, and adherence to standards are key to ensuring system integrity.
- Continuous evaluation and maintenance are essential for long-term performance.

Maximizing the effectiveness of HDPE piping systems hinges on understanding the maximum allowable span?

Question What is the maximum allowable span for HDPE pipes in residential irrigation systems? The maximum allowable span for HDPE pipes in residential irrigation typically ranges from 4 to 6 meters, depending on pipe diameter and load conditions, as per manufacturer guidelines and local standards. **Answer** How does pipe diameter affect the maximum allowable span for HDPE pipes? Larger diameter HDPE pipes generally have a greater maximum allowable span due to their increased strength and stiffness, reducing the need for intermediate supports compared to smaller diameter pipes. Are there specific codes or standards that define the maximum span for HDPE pipes? Yes, standards such as ASTM D3035, ISO 4427, and local building codes provide guidelines on maximum spans, typically based on pipe size, load conditions, and installation environment. How does soil load influence the maximum span of buried HDPE pipes? Higher soil loads increase the pipe's deflection and stress, thereby reducing the maximum allowable span; proper bedding and backfill are essential to optimize span limits. Can ambient temperature affect the maximum span of HDPE pipes? Yes, elevated temperatures can soften HDPE material, potentially reducing its load-bearing capacity and thus decreasing the maximum allowable span to prevent deformation. Is it necessary to support HDPE pipes at regular intervals for maximum span optimization? Yes, supporting HDPE pipes at recommended intervals, often specified by manufacturers, helps prevent sagging and ensures structural integrity, especially over longer spans. How do installation conditions influence the maximum span for HDPE pipes? Factors such as bedding quality, load from traffic or machinery, and environmental conditions can reduce the maximum span, necessitating shorter supports or additional reinforcement. What is the typical maximum span for large-diameter HDPE pipes used in municipal water systems? For large-diameter HDPE pipes in municipal applications, spans can range from 10 to 20 meters or more, depending on specific design criteria, support methods, and manufacturer recommendations. How can engineers determine the appropriate maximum span for HDPE pipes in a project? Engineers should consider pipe diameter, material properties, load conditions, installation environment, and applicable standards, often performing structural analysis or consulting manufacturer guidelines to determine suitable spans.

Related keywords: HDPE pipe span, maximum span length, pipe support spacing, allowable span distance, pipe load capacity, pipe installation guidelines, engineering standards HDPE, structural design HDPE pipe, load limits HDPE, pipeline span regulations

Read the full article online: [maximum allowable span for hdpe pipe](#)

maximum pipe span chart

Maximum Pipe Span Chart: A Comprehensive Guide for Engineers and Contractors

Understanding the maximum pipe span chart is essential for architects, engineers, contractors, and plumbing professionals involved in designing and installing piping systems. Proper pipe span calculations ensure the structural integrity, safety, and longevity of the piping infrastructure. This article provides an in-depth overview of the maximum pipe span chart, its importance, factors influencing pipe spans, standard guidelines, and practical applications.

What is a Maximum Pipe Span Chart?

A maximum pipe span chart is a visual or tabular reference tool that indicates the maximum allowable distance between supports (such as hangers, brackets, or supports) for various pipe sizes, materials, and load conditions. It helps determine how far apart supports can be placed without risking excessive deflection, vibration, or failure.

Key Components of a Pipe Span Chart:

- Pipe diameter and size
- Pipe material (e.g., steel, PVC, copper)
- Pipe thickness or schedule
- Support spacing (span)
- Load conditions (full or partial)
- Temperature considerations

Importance of the Maximum Pipe Span Chart

Using an accurate maximum pipe span chart ensures:

- Structural safety: Prevents pipe sagging, cracking, or breaking.
- System efficiency: Maintains proper flow and reduces pressure loss.
- Compliance: Meets building codes and standards.
- Cost-effectiveness: Avoids over-supporting, reducing material costs.
- Longevity: Extends the lifespan of the piping system.

Factors Influencing Maximum Pipe Span

Several factors impact the maximum allowable span for pipes:

1. Pipe Material

Different materials have varying strengths and flexibility:

- Steel pipes (e.g., carbon steel, stainless steel) generally support larger spans.
- Plastic pipes (PVC, CPVC, PEX) are more flexible and require closer supports.
- Copper pipes have moderate support requirements.

2. Pipe Diameter and Thickness

Larger diameters and thicker walls can bear more load but may also be heavier, influencing support spacing.

3. Load Conditions

- Full load: When the pipe is filled with fluid.
- Partial load: When the pipe is only partially filled.
- The weight of the fluid and pipe material impacts support requirements.

4. Temperature

Higher temperatures can cause expansion, requiring adjustments in support spacing.

5. Support Type and Material

Clamps, hangers, and brackets vary in strength and influence the maximum span.

Standard Guidelines for Pipe Spanning

Various organizations and codes provide guidelines for pipe support spacing. Here are some common standards:

1. Steel Pipes (e.g., Black Steel, Galvanized)

| Pipe Size | Support Spacing (Maximum) | Reference Standard |

-----	-----	-----
-------	-------	-------

| 1/2" | 3-4 ft | ASME B36.10 / B36.19 |

| 1" | 4-5 ft | ASME B36.10 / B36.19 |

| 2" | 5-6 ft | ASME B36.10 / B36.19 |

Note: Larger diameters may require supports at closer intervals due to increased weight.

2. PVC and Plastic Pipes

| Pipe Size | Support Spacing (Maximum) | Reference Standard |

-----	-----	-----
-------	-------	-------

| 1/2" | 3-4 ft | ASTM D1785, UPC |

| 1" | 4-5 ft | ASTM D1785, UPC |

| 2" | 4-6 ft | ASTM D1785, UPC |

Note: Plastic pipes are more flexible, so support spacing is slightly more forgiving but still requires adherence to standards.

3. Copper Pipes

| Pipe Size | Support Spacing (Maximum) | Reference Standard |

-----	-----	-----
-------	-------	-------

| 1/2" | 3-4 ft | Copper Tube Handbook |

| 1" | 4-5 ft | Copper Tube Handbook |

Creating a Pipe Span Chart: Step-by-Step

To develop a custom maximum pipe span chart tailored to specific project needs, follow these steps:

- **Identify Pipe Material and Size:** Determine the pipe type and diameter.

- **Assess Load Conditions:** Calculate the total weight, including fluid and pipe material.
- **Consult Standards and Codes:** Use established guidelines from ASME, ASTM, UPC, or other relevant standards.
- **Determine Support Type:** Decide on the type of support (e.g., rigid, flexible) and support material.
- **Calculate Support Spacing:** Using the data and load calculations, determine the maximum span that maintains safe deflection limits.
- **Document and Verify:** Record the span distances and verify against industry standards and manufacturer recommendations.

Practical Applications of the Maximum Pipe Span Chart

The maximum pipe span chart is used across various industries:

1. Building Plumbing Systems

Ensuring proper support spacing in residential, commercial, and industrial plumbing to prevent sagging and leaks.

2. Fire Protection Systems

Supporting large-diameter pipes in sprinkler systems to maintain system integrity.

3. HVAC Ductwork and Piping

Designing support systems that accommodate thermal expansion and vibration.

4. Industrial Piping

Supporting process pipes carrying chemicals, gases, or high-temperature fluids.

5. Infrastructure Projects

Designing large-scale pipelines for water, sewage, or oil transportation.

Common Mistakes to Avoid When Using Pipe Span Charts

While using maximum pipe span charts, it's important to avoid common pitfalls:

- **Ignoring load variations:** Failing to account for full fluid load or additional weight.

- **Not considering thermal expansion:** Overlooking temperature effects can lead to unsupported expansion or contraction.
- **Using outdated standards:** Always verify that the chart aligns with current codes and standards.
- **Overlooking support quality:** Poor support materials or installation can compromise support effectiveness.
- **Neglecting local building codes:** Always verify compliance with local regulations.

Conclusion

The maximum pipe span chart is an indispensable tool for ensuring the safety, efficiency, and durability of piping systems. By understanding the factors influencing support spans and adhering to established standards, professionals can design piping systems that meet safety requirements and operational needs. Always consult relevant standards and manufacturer recommendations when developing or applying a pipe span chart to ensure compliance and optimal performance.

Proper support spacing not only safeguards the structural integrity of the piping but also contributes to the overall success of construction and maintenance projects. Whether working with steel, plastic, or copper pipes, a detailed and accurate maximum pipe span chart is essential for effective and compliant piping system design.

Remember: Regularly update your knowledge base with the latest standards and technological advancements to ensure your piping systems are built to the highest safety and performance standards.

Maximum Pipe Span Chart: An Expert Guide to Optimal Pipe Support and Design

When designing plumbing, HVAC, or industrial piping systems, understanding how to properly support pipes is crucial for safety, efficiency, and longevity. The Maximum Pipe Span Chart serves as an essential reference tool for engineers, contractors, and maintenance professionals, providing critical data on the maximum allowable distances between pipe supports based on various factors. This article offers an in-depth exploration of the maximum pipe span chart, its significance, how to interpret it, and practical applications in piping system design.

What Is a Maximum Pipe Span Chart?

A Maximum Pipe Span Chart is a comprehensive diagram or table that specifies the maximum permissible distances between supports or hangers for pipes of different sizes, materials, and operating conditions. It ensures that pipes are adequately supported to prevent sagging, deformation, or failure under their own weight, internal pressure, or external loads.

Purpose and Importance

- Structural Integrity: Proper support minimizes stress on pipes, preventing deformation or rupture.
- Safety Compliance: Ensures adherence to building codes and standards such as the International Mechanical Code (IMC) or ASME B31.1/B31.3.
- Cost Efficiency: Optimizes the number of supports, balancing material costs with safety margins.
- System Longevity: Proper support reduces wear and tear, extending the lifespan of piping systems.

Factors Influencing the Chart

- Pipe material (e.g., steel, copper, PVC)
- Pipe size (diameter and wall thickness)
- Pipe type (e.g., rigid, flexible)
- Operating temperature and pressure
- External loads (e.g., insulation, vibrations)
- Installation method (e.g., hung from ceiling, supported on brackets)

Understanding the Components of the Pipe Span Chart

The maximum pipe span chart is typically organized into sections based on pipe diameter, material, and application. The key components include:

- Pipe Size and Diameter

Larger diameter pipes generally require more frequent supports due to increased weight. The chart lists standard pipe sizes, often in inches or millimeters.

- Support Spacing (Span)

This indicates the maximum distance between supports, usually in feet or meters. Exceeding these distances risks pipe deflection or damage.

- Pipe Material

Different materials have varying strengths and thermal properties, influencing support requirements:

- Steel and cast iron: high strength, longer spans
 - Copper: moderate strength
 - PVC and plastic: lower strength, shorter spans
-
- Operating Conditions

Temperature and pressure affect pipe flexibility and support needs. For example, hot water pipes may require closer supports due to thermal expansion.

- Support Type

The chart may specify support types like clamps, hangers, or brackets, which can influence allowable spans.

How to Read and Interpret a Maximum Pipe Span Chart

Proper interpretation of the chart involves understanding the relationship between pipe size, material, and support spacing. Here's a step-by-step guide:

Step 1: Identify Pipe Size and Material

Locate the specific pipe diameter and material in the chart. For example, a 2-inch galvanized steel pipe.

Step 2: Determine Operating Conditions

Assess whether the pipe carries hot or cold fluids, as this impacts support distance due to thermal expansion.

Step 3: Find Corresponding Support Span

Match the pipe's operational parameters to the recommended maximum span. For instance, the chart may recommend supports every 10 feet for a 2-inch steel pipe.

Step 4: Consider External Factors

Adjust spans based on additional loads (insulation, vibration), which may necessitate shorter supports.

Step 5: Apply Support Spacing in Design

Use the chart data to plan support placement, ensuring compliance with safety and code standards.

Sample Maximum Pipe Span Chart Overview

While actual charts vary depending on standards and manufacturers, a typical maximum pipe span chart might look like this:

Pipe Diameter	Material	Max Support Spacing (ft)	Notes
-----	-----	-----	-----
1/2 inch	Steel	6	For standard temperature and pressure
1 inch	Copper	8	Adjust for thermal expansion
2 inches	PVC	4	Shorter spans due to material strength
3 inches	Cast Iron	10	Suitable for heavy-duty applications

Note: These values are illustrative; consult specific standards for precise data.

Standards and Guidelines for Pipe Support Spacing

Several organizations establish standards for pipe support spacing, including:

- ASME B31.1 and B31.3
- Provide detailed guidelines for power and process piping.
- Specify support spacing based on pipe size, material, and operating conditions.
- International Mechanical Code (IMC)

- Contains requirements for pipe supports in building systems.
- Emphasizes safety and fire protection.
- Manufacturer Recommendations
- Some pipe manufacturers provide specific support guidelines tailored to their products.

Key Points from Standards

- Supports should be placed at intervals not exceeding the maximum span.
- For flexible piping (e.g., plastic), supports may need to be closer.
- Special considerations apply for horizontal, vertical, or inclined pipe runs.

Practical Applications of the Maximum Pipe Span Chart

Understanding and utilizing the chart effectively impacts various aspects of piping system design:

- New Installations
 - Ensures supports are correctly spaced from the outset, reducing future maintenance costs.
 - Helps in planning support locations during layout design.
- System Modifications
 - When upgrading or modifying existing systems, refer to the chart to evaluate if current supports are adequate.
- Maintenance and Inspection
 - Regular inspections should verify support integrity and adherence to recommended spans.

- Energy Efficiency
- Proper support reduces vibrations and leaks, contributing to system efficiency.
- Code Compliance and Certification
- Using the chart ensures compliance with legal and safety standards, facilitating inspections and certifications.

Limitations and Considerations

While the maximum pipe span chart is a vital tool, it isn't exhaustive. Users should consider:

- Material Variations: Different brands or manufacturing processes may affect strength.
- Environmental Conditions: Exposure to seismic activity, wind, or corrosive environments may require additional supports.
- Thermal Expansion: Hot water or steam lines may need supports that accommodate expansion and contraction.
- Vibration and Movement: Machinery or external sources can necessitate closer supports.
- Aesthetic and Accessibility Requirements: Support placement should balance functional and visual considerations.

Conclusion: The Significance of the Maximum Pipe Span Chart in Piping Design

The Maximum Pipe Span Chart is more than just a reference; it is a foundational tool underpinning the safety, efficiency, and durability of piping systems. Proper understanding and application of the chart help prevent structural failures, ensure compliance with code standards, and optimize material use.

For engineers, contractors, and maintenance teams, familiarity with the chart's data ensures informed decision-making during installation and maintenance. As piping systems evolve with new materials and technologies, staying updated with current standards and manufacturer guidelines remains essential.

In essence, leveraging the maximum pipe span chart is a best practice that safeguards investments, protects lives, and guarantees the reliable operation of piping infrastructure for years to come.

Question What is a maximum pipe span chart and why is it important? A maximum pipe span chart illustrates the maximum allowable span between supports for pipes of different sizes and materials, ensuring safe and efficient piping system design by preventing excessive deflection or failure. **Answer** How do I interpret a maximum pipe span chart? To interpret a maximum pipe span chart, locate the pipe diameter and material, then read across to find the corresponding maximum span length between supports, which helps determine proper support placement in your installation. What factors influence the maximum span of a pipe? Factors include pipe material, diameter, wall thickness, fluid type and pressure, temperature, and support type, all of which affect how far a pipe can span safely without excessive deflection or damage. Can a maximum pipe span chart be used for all pipe materials? No, different pipe materials have different strength and flexibility characteristics; therefore, maximum span charts are specific to each material type and should be used accordingly. How does pipe diameter affect the maximum span according to the chart? Generally, larger diameter pipes require shorter spans between supports due to increased weight and potential deflection, which is reflected in the chart by decreasing maximum span values as diameter increases. Are maximum pipe span charts applicable to both indoor and outdoor piping systems? Yes, but it's important to select the chart that matches the specific conditions, including environmental factors, pipe material, and installation type, to ensure accurate support spacing recommendations. What are the consequences of exceeding the maximum span indicated on the chart? Exceeding the maximum span can lead to excessive pipe deflection, sagging, stress, or failure, which may cause leaks, pipe damage, or system failure, compromising safety and performance. Where can I find reliable maximum pipe span charts for different pipe materials? Reliable charts can be obtained from manufacturer catalogs, industry standards such as ASME or ASTM, plumbing codes, or specialized piping design software that reference approved support spans. How often should support spacing be checked or updated based on maximum pipe span charts? Support spacing should be checked during installation and periodically inspected during maintenance to ensure compliance with the maximum span guidelines, especially if pipe conditions or system requirements change.

Related keywords: pipe span chart, pipe span calculator, pipe span distance, pipe support guide, pipe load capacity, maximum pipe length, pipe support spacing, pipe stress chart, pipe installation guidelines, allowable pipe span

Read the full article online: [MAXIMUM PIPE SPAN CHART](#)

Math for the sprinkler fitter study guide

Math for the Sprinkler Fitter Study Guide

Preparing for a career as a sprinkler fitter requires a solid understanding of various technical skills, among which math plays a crucial role. Math for the sprinkler fitter study guide is an essential resource that helps aspiring professionals master the calculations necessary for designing, installing, and maintaining effective fire sprinkler systems. This comprehensive guide aims to demystify the mathematical concepts involved, providing clear explanations, practical examples, and tips to succeed in your certification exams and on-the-job tasks.

Understanding the importance of math in sprinkler fitting is vital. From determining pipe sizes and flow rates to calculating water pressure and system layout, accurate mathematical calculations ensure safety, efficiency, and compliance with industry standards. This article will explore the key mathematical principles relevant to sprinkler fitting, offering step-by-step guidance to help you develop confidence in your math skills.

Fundamental Mathematical Concepts for Sprinkler Fitters

Before diving into specific calculations, it's important to review foundational mathematical concepts that form the basis of more complex sprinkler fitting calculations.

Basic Arithmetic Operations

- Addition, subtraction, multiplication, and division are the building blocks of all calculations.
- Precision in these operations is critical to prevent errors that could compromise system safety.

Fractions, Decimals, and Ratios

- Understanding how to convert between fractions and decimals.
- Using ratios to compare different quantities, such as pipe diameters or flow rates.

Units of Measurement

- Familiarity with units such as gallons per minute (GPM), pounds per square inch (PSI), feet (ft), inches (in), and meters (m).
- Converting between units to ensure consistency in calculations.

Algebra and Formulas

- Solving for unknown variables using algebraic equations.

- Applying formulas specific to sprinkler systems, such as those for flow rate and pressure loss.

Key Calculations in Sprinkler System Design

Sprinkler fitters rely heavily on specific calculations to ensure that systems operate effectively and safely. Below are the most common calculations you will encounter.

Flow Rate Calculations

Flow rate determines how much water is delivered to the sprinkler heads within a given time frame.

Formula:

$$Q = N \times G$$

Where:

- Q = Total flow rate (GPM)
- N = Number of sprinklers
- G = Flow rate per sprinkler (GPM)

Example:

If a system has 20 sprinklers, each requiring 10 GPM, the total flow rate is:

$$Q = 20 \times 10 = 200 \text{ GPM}$$

Pressure Loss Calculations

Calculating pressure loss is vital to ensure the system maintains adequate pressure at each sprinkler.

Darcy-Weisbach Equation (Simplified):

$$\Delta P = \frac{4 \times f \times L \times V^2}{D \times 2g}$$

Where:

- ΔP = Pressure loss (Pascals or PSI)

- f = Friction factor (depends on pipe roughness)
- L = Length of pipe (feet or meters)
- V = Velocity of water (ft/sec or m/sec)
- D = Diameter of pipe (feet or meters)
- g = Acceleration due to gravity

Simplified Approach:

For practical purposes, using charts or online calculators to estimate pressure loss based on flow rate and pipe size is common.

Pipe Sizing Calculations

Proper pipe sizing ensures sufficient flow and pressure.

Method:

- Determine total flow rate (GPM).
- Consult pipe flow charts or use formulas to find the minimum pipe diameter that can handle the flow with acceptable pressure loss.
- Confirm the selected pipe size complies with manufacturer specifications and code requirements.

Water Supply Calculations

Ensuring the water supply can meet the demands of the sprinkler system involves several calculations.

Flow Rate Requirements

- Sum the flow rates of all sprinkler heads in the most demanding zone.
- Ensure the main supply and branches can deliver this flow.

Static and Residual Pressure

- Static pressure: the pressure when no water is flowing.
- Residual pressure: the pressure during system operation.
- Use pressure loss calculations to verify that residual pressure remains above the minimum

required at the most remote sprinkler head.

Calculating System Layout and Spacing

Proper placement of sprinkler heads maximizes coverage and minimizes water wastage.

Sprinkler Head Spacing

- Typical spacing ranges from 10 to 15 feet apart.
- Use the "Coverage Area" formula:

$$\text{Area} = \pi r^2$$

where r is the radius of coverage, depending on head type and pressure.

Example:

A sprinkler head covers a radius of 12 feet:

$$\text{Coverage Area} = \pi \times 12^2 \approx 452 \text{ sq ft}$$

Layout Planning

- Use scaled drawings and measurements.
- Ensure overlapping coverage zones to prevent dead spots.
- Follow local codes and standards for head spacing and placement.

Common Mathematical Conversions and Tips

Being proficient in conversions simplifies calculations and prevents errors.

Conversions to Know:

- 1 foot = 12 inches
- 1 inch = 0.0833 feet
- 1 GPM = 0.0658 gallons per second
- 1 PSI = 2.31 feet of water head

Tip:

Always double-check unit consistency before performing calculations.

Practical Tips for Mastering Math for Sprinkler Fitting

- Practice with real-world scenarios to build confidence.
- Use calculator functions or software for complex calculations.
- Memorize common formulas and conversion factors.
- Keep a reference sheet of industry standards and typical values.
- Attend training courses that emphasize math skills in sprinkler fitting.

Conclusion

Math for the sprinkler fitter study guide is an indispensable resource that empowers you to design safe, efficient, and compliant fire sprinkler systems. Mastering the core concepts of flow rate, pressure calculations, pipe sizing, and system layout ensures you can perform your duties with accuracy and confidence. Consistent practice, understanding of fundamental principles, and familiarity with industry standards will pave the way for success in certification exams and on-the-job applications. Embrace the learning process, utilize available tools, and remember that precise math is the backbone of reliable sprinkler system installation and maintenance.

Math for the Sprinkler Fitter Study Guide: A Comprehensive Review and Analytical Insight

Sprinkler fitting is a specialized trade that demands a solid grasp of mathematical principles to ensure the accurate design, installation, and maintenance of fire protection systems. For aspiring sprinkler fitters, mastering the mathematical concepts outlined in the study guide is essential, not only for passing certification exams but also for executing work that adheres to safety standards and industry codes. This article provides an in-depth exploration of the key mathematical topics relevant to sprinkler fitters, breaking down complex ideas into accessible explanations and analyzing their practical applications within the field.

Understanding the Role of Mathematics in Sprinkler Fitting

Sprinkler fitters operate at the intersection of engineering, safety compliance, and craftsmanship. Their work involves calculating pipe sizes, determining flow rates, and ensuring that systems meet precise specifications. Mathematics serves as the backbone for these tasks, enabling fitters to design systems that are both functional and compliant with fire code regulations.

The importance of math in sprinkler fitting cannot be overstated. Errors in calculations can lead to

inadequate water coverage, system failures, or safety hazards. Therefore, proficiency in relevant mathematical concepts is fundamental for successful performance and certification.

Basic Mathematical Fundamentals

Before delving into advanced calculations, a solid foundation in basic math skills is necessary. This includes:

1. Arithmetic Operations

- Addition, subtraction, multiplication, and division are fundamental for all calculations.
- Understanding order of operations (PEMDAS) ensures correct results in complex formulas.

2. Fractions, Decimals, and Percentages

- Fractions and decimals are used interchangeably in measurements.
- Percentages are useful for calculating flow efficiencies and pressure drops.

3. Units of Measurement

- Familiarity with imperial (feet, inches, gallons) and metric units (meters, liters) is crucial.
- Conversion between units often required; for instance, converting inches to feet or gallons to liters.

Key Mathematical Concepts for Sprinkler Fitting

The following sections explore the core mathematical principles that underpin sprinkler fitting calculations.

1. Area and Volume Calculations

Understanding the cross-sectional area of pipes and the volume of water they carry is essential.

- Area of a Circle: $(A = \pi r^2)$
- Used to determine the cross-sectional area of pipes based on diameter.
- Example: For a pipe with a diameter of 4 inches, radius is 2 inches, so $(A = \pi \times 2^2 = 12.57 \text{ in}^2)$.

- Volume of Water Flow:
- Volume flow rate (Q) relates to pipe cross-section and velocity.
- $(Q = A \times v)$, where (v) is velocity.
- Calculating volume helps determine if the system can deliver adequate water flow.

2. Fluid Dynamics and the Continuity Equation

Sprinkler systems depend on fluid flow principles.

- Continuity Equation:
- States that $(A_1 v_1 = A_2 v_2)$ in a closed system.
- If pipe diameter decreases, velocity must increase to maintain flow rate.
- Critical for designing piping that maintains consistent water delivery.

3. Pressure and Head Loss Calculations

Pressure must be sufficient to deliver water to all sprinklers.

- Hydraulic Head:
- Represents energy per unit weight of water.
- Measured in feet or meters.

- Head Loss due to Friction:
- Calculated using Darcy-Weisbach or Hazen-Williams equations.
- Example (Hazen-Williams):

[

$$h_f = 10.67 \times \frac{L \times Q^{1.85}}{C^{1.85} \times d^{4.87}}$$

]

where:

- (h_f) : head loss (feet)
- (L) : pipe length (feet)
- (Q) : flow rate (gpm)

- C : Hazen-Williams roughness coefficient
 - d : pipe diameter (inches)
- Precise head loss calculations ensure the system maintains adequate pressure at all points.

4. Pipe Sizing and Flow Rate Calculations

Choosing the correct pipe size is vital to system performance.

- Flow Rate Calculation:
 - Based on the area and velocity: $Q = A \times v$.
 - Must meet the minimum flow requirements per fire code.
- Selecting Pipe Diameter:
 - Balances flow capacity and pressure loss.
 - Larger diameter pipes reduce head loss but increase material costs.

Mathematical Formulas in Practice

In real-world applications, sprinkler fitters rely on formulas and calculations for system design.

Example 1: Calculating Pipe Cross-Sectional Area

Suppose a system uses 2.5-inch diameter pipes:

$$A = \pi \times \left(\frac{d}{2}\right)^2 = 3.1416 \times (1.25)^2 \approx 4.91 \text{ in}^2$$

This area helps determine flow capacity and pressure drop.

Example 2: Determining Flow Rate

If the water velocity is 10 ft/sec in a 2-inch pipe:

- Convert diameter to radius: $(r = 1 \text{ inch} = \frac{1}{12} \text{ ft})$.
- Cross-sectional area:

[

$A = \pi \times r^2 = 3.1416 \times \left(\frac{1}{12}\right)^2 \approx 0.0218 \text{ ft}^2$

]

- Flow rate:

[

$Q = A \times v = 0.0218 \times 10 = 0.218 \text{ ft}^3/\text{s}$

]

- Converting to gallons per minute (gpm):

[

$1 \text{ ft}^3/\text{s} = 448.831 \text{ gpm}$

]

[

$Q = 0.218 \times 448.831 \approx 97.8 \text{ gpm}$

]

This calculation guides the selection of pump capacity and pipe diameter.

Advanced Topics and Analytical Techniques

Beyond basic calculations, sprinkler fitters often need to analyze complex systems using advanced mathematical techniques.

1. System Curves and Pump Selection

Designing a system involves creating a system curve representing head loss versus flow rate.

- Analytical approach involves plotting head loss equations against desired flow rates.
- Ensures pump selection matches system requirements.

2. Use of Software and Calculators

Modern sprinkler fitting projects often utilize computer-aided design (CAD) and hydraulic calculation software.

- These tools automate complex calculations, reduce errors, and optimize system design.
- Nevertheless, understanding the underlying math remains essential for troubleshooting and verification.

3. Safety Margins and Code Compliance

Mathematical analysis includes incorporating safety margins to account for variances in water supply and pressure fluctuations.

- Design systems with buffer capacity, typically 10-20% above minimum requirements.
- Ensures reliability and compliance with standards such as NFPA 13.

Integrating Math Skills into Certification and Fieldwork

Proficiency in these mathematical concepts is critical for passing certification exams, which test knowledge through problem-solving scenarios.

- Practice with real-world problems enhances understanding.
- Fieldwork requires quick, accurate calculations under pressure?fluid dynamics, pipe sizing, and pressure calculations are routine tasks.

Continuous learning and application of mathematical principles foster safer, more efficient sprinkler systems, ultimately protecting lives and property.

Conclusion

Mastering the mathematical aspects of sprinkler fitting transforms theoretical knowledge into

practical expertise. From basic calculations of pipe areas to complex hydraulic modeling, math underpins every step of the sprinkler system lifecycle. Aspiring fitters who develop a thorough understanding of these concepts will be better equipped to design compliant, efficient, and reliable fire protection systems. As technology advances and codes evolve, the ability to apply mathematical reasoning remains a cornerstone of excellence in sprinkler fitting.

In summary, the math for the sprinkler fitter study guide encompasses fundamental arithmetic, geometric calculations, fluid mechanics, and system analysis, each playing a vital role in ensuring safety, efficiency, and compliance in fire sprinkler systems. Developing proficiency in these areas not only prepares candidates for certification but also enhances their capability to perform high-quality work in the field.

Question What basic math concepts should I master for the sprinkler fitter exam? You should be comfortable with algebra, geometry, unit conversions, and calculations involving area, volume, and pipe measurements to ensure accurate planning and installation. **Answer** How do I calculate the flow rate needed for a sprinkler system? Flow rate is calculated by dividing the total water demand (in gallons per minute) by the number of sprinklers operating simultaneously, ensuring each sprinkler receives adequate water pressure. What is the importance of understanding pipe measurements and conversions? Accurate pipe measurements and conversions are crucial for proper system layout, ensuring the correct pipe sizes are used and that the system functions efficiently without pressure loss. How do I determine the head pressure in a sprinkler system? Head pressure is determined by calculating the height difference from the water source to the sprinkler point and considering friction losses within the piping system, often using pressure loss formulas. What role does geometry play in designing sprinkler layouts? Geometry helps in determining the placement of sprinklers to ensure uniform coverage, calculating distances, and designing layouts that optimize water distribution efficiently. How can I estimate the volume of water used per sprinkler zone? Multiply the flow rate per sprinkler by the number of sprinklers in the zone and the duration of operation to estimate the total water volume used. Why is understanding pressure and flow calculations critical for sprinkler systems? Proper pressure and flow calculations ensure that each sprinkler receives adequate water, preventing dry spots or over-pressurization that could damage the system. Are there specific math formulas I should memorize for the sprinkler fitter exam? Yes, formulas related to flow rate calculations, pressure loss, pipe sizing, and volume estimation are essential to confidently solve practical problems on the exam.

Related keywords: sprinkler fitter exam, fire protection systems, hydraulic calculations, sprinkler system design, fire sprinkler codes, fire protection engineering, fire sprinkler installation, NFPA standards, fire suppression systems, plumbing and piping

Read the full article online: [Math for the sprinkler fitter study guide](#)

Pipe Support Span Calculation

Pipe support span calculation is a critical aspect of piping system design that ensures safety, integrity, and longevity of the piping infrastructure. Proper support placement prevents excessive deflection, reduces stress on pipes, minimizes vibration, and helps maintain the system's operational efficiency. Whether designing for industrial plants, residential plumbing, or high-pressure systems, understanding how to accurately calculate and determine the appropriate span between pipe supports is essential for engineers, designers, and maintenance personnel.

Understanding the Importance of Pipe Support Spans

Proper pipe support span calculation is fundamental for several reasons:

- Preventing Pipe Deformation: Excessive span can lead to bending and deformation under the weight of the pipe and contained fluids.
- Reducing Stress and Fatigue: Proper support minimizes stress concentrations that could cause cracks or failures over time.
- Controlling Vibration and Noise: Correct support placement dampens vibrations, which are especially critical in high-flow systems.
- Ensuring Compliance: Many codes and standards specify maximum allowable spans to ensure safety and reliability.

Factors Influencing Pipe Support Span Calculation

Effective calculation depends on multiple factors, which include:

- Pipe Material: Steel, PVC, copper, and other materials have different flexural strengths.
- Pipe Diameter and Thickness: Larger and thicker pipes are more rigid but also heavier.
- Pipe Weight: Includes the weight of the pipe itself plus the contents.
- Support Type: Fixed, sliding, or spring supports influence how loads are distributed.
- Fluid Characteristics: Viscosity, flow rate, and temperature can affect pipe behavior.
- Environmental Conditions: External factors like temperature fluctuations, wind, and seismic activity.

Standards and Guidelines for Pipe Support Spans

Several standards govern pipe support span calculations, ensuring uniformity and safety:

- ASME B31.3 (Process Piping): Provides guidelines for support spacing based on pipe size and material.
- API Standards: For oil and gas pipelines, API standards specify support practices.
- ISO Standards: Offer international guidelines for piping support and installation.
- Local Building Codes: May impose additional requirements depending on jurisdiction.

Calculating Pipe Support Spans: Step-by-Step Approach

Calculating pipe support spans involves a systematic process. Here's a detailed methodology:

Step 1: Gather Essential Data

Before starting calculations, collect:

- Pipe material and specifications (diameter, wall thickness)
- Pipe length and configuration
- Pipe and fluid weight
- Support type and positioning constraints
- Environmental and operational conditions

Step 2: Determine Pipe Weight

Calculate the weight of the pipe per unit length:

\[

$$W_{\text{pipe}} = \text{Material density} \times \text{Volume per unit length}$$

\]

For a circular pipe:

\[

$$W_{\text{pipe}} = \rho_{\text{material}} \times \pi \times \left(R_{\text{outer}}^2 - R_{\text{inner}}^2 \right)$$

\]

where:

- (R_{outer}) = outer radius
- (R_{inner}) = inner radius

Add the weight of the contained fluid if significant.

Step 3: Identify Maximum Allowable Deflection

Design standards specify permissible deflection limits, often expressed as a fraction of the span or pipe diameter, such as:

- 1/200 of the span
- 1/20 of the span for certain applications

This limit ensures the pipe maintains its structural integrity and operational efficiency.

Step 4: Select Suitable Support Types

Support types influence span calculations:

- Rigid Supports: Fixed or anchored supports with minimal movement.
- Sliding Supports: Allow for thermal expansion and contraction.
- Spring Supports: Absorb loads dynamically.

The support choice affects the maximum span, as some supports can handle longer spans due to flexibility.

Step 5: Calculate Support Span Using Flexural and Load Data

Using beam theory principles, the maximum span (L) can be estimated with the formula:

$$L = \left(\frac{K \times E \times I \times \Delta_{max}}{W_{total}} \right)^{1/4}$$

where:

- (K) = a constant depending on support conditions
- (E) = modulus of elasticity of pipe material
- (I) = moment of inertia
- $(\Delta_{\max})$ = maximum permissible deflection
- (W_{total}) = total load per unit length

Alternatively, for practical purposes, industry tables and software tools are often used to determine spans based on empirical data aligned with standards.

Practical Guidelines and Typical Support Spans

While precise calculations are necessary for critical systems, general guidelines for support spans are:

- Steel Pipes: Typically support every 3 to 6 meters (10 to 20 feet) depending on diameter and thickness.
- PVC and Plastic Pipes: Usually supported every 1.5 to 3 meters (5 to 10 feet).
- High-Temperature or High-Pressure Systems: Require closer supports, sometimes every 1 to 2 meters (3 to 6 feet).

Always consult relevant standards for specific applications, as these figures can vary based on conditions.

Design Considerations for Optimal Pipe Support Spans

In addition to calculation accuracy, consider the following for robust piping systems:

- Thermal Expansion: Include expansion loops or flexible supports.
- Accessibility: Ensure supports allow easy inspection and maintenance.
- Vibration Control: Use damping supports or isolators if needed.
- Load Distribution: Avoid concentrated loads that could overstress supports.
- Corrosion and Wear: Choose durable support materials compatible with pipe material and environment.

Common Tools and Software for Support Span Calculation

Modern engineering leverages technology for accurate and efficient calculations:

- Finite Element Analysis (FEA) Software: ANSYS, SAP2000, or specialized piping analysis tools.
- Support Spacing Tables: Published in standards and handbooks.
- Spreadsheet Models: Custom spreadsheets tailored to specific project requirements.
- CAD Integration: Supports visualization and dynamic adjustment of support locations.

Conclusion: Ensuring Safety and Reliability Through Proper Support Span Calculation

Accurate pipe support span calculation is a cornerstone of effective piping system design. It combines fundamental engineering principles, industry standards, and practical experience to determine optimal support placement. By thoroughly analyzing factors such as pipe weight, material properties, environmental conditions, and support types, designers can prevent structural failures, reduce maintenance costs, and ensure compliance with safety regulations. Employing proper calculation methods and leveraging available tools ultimately leads to safer, more durable, and efficient piping systems that serve their intended purpose reliably over their operational lifespan.

References and Further Reading

- ASME B31.3 Process Piping Code
- API Standard 650 Welded Tanks for Oil Storage
- ISO 14692 Petroleum and natural gas industries ? Glass-reinforced plastics piping
- "Piping Design and Engineering" by M. S. Ramachandra Rao
- Industry support span tables and guidelines from piping material manufacturers

Remember: Accurate support span calculation is not just about adhering to standards; it's about ensuring safety, efficiency, and longevity of your piping infrastructure. Always verify calculations with current standards and consult experienced engineers when designing critical systems.

Pipe support span calculation is a fundamental aspect of piping design and installation, ensuring the structural integrity, safety, and longevity of piping systems. Properly calculating the support span helps prevent sagging, excessive deflection, and potential failure of pipes under various load conditions. Whether you're an engineer, designer, or installer, understanding how to accurately determine support spans is critical to maintaining compliance with codes and optimizing system performance.

Introduction to Pipe Support Span Calculation

Pipe support span calculation involves determining the maximum distance between supports for a pipe of specified material, diameter, and operating conditions. This calculation considers factors such as pipe weight, contents, environmental loads, and the type of support used. Proper support

spans ensure that the pipe remains stable, minimizes stress concentrations, and adheres to safety standards.

Why Is Correct Support Span Important?

- Prevents sagging and deformation: Excessive span can lead to pipe sagging, causing flow issues or mechanical stress.
- Reduces stress and fatigue: Proper support reduces stress concentrations that could lead to fatigue failure over time.
- Maintains alignment and system integrity: Properly supported pipes stay aligned, reducing wear and potential leaks.
- Ensures compliance: Many codes and standards specify maximum support spans for different pipe sizes and materials.

Factors Influencing Pipe Support Span Calculation

Several key factors influence the calculation of pipe support spans, including:

- Pipe Material and Wall Thickness

Different materials (e.g., carbon steel, stainless steel, plastic) have varying stiffness and weight, affecting how much they can span between supports.

- Pipe Diameter and Wall Thickness

Larger diameter and thicker pipes are heavier and more prone to sagging, requiring shorter spans.

- Pipe Operating Conditions

- Fluid type and pressure: Pressurized or viscous fluids increase pipe weight and stress.
- Temperature: Elevated temperatures can cause expansion or softening, affecting support requirements.

- Support Type

- Hangers, clamps, saddle supports: Each provides different support characteristics.
- Fixed or sliding supports: Influence allowable span due to movement allowances.
- Environmental Loads
 - Wind, seismic activity, and thermal expansion: External factors that impose additional loads.
- Relevant Codes and Standards

Standards such as ASME B31.3, ASME B31.1, and API 650 provide guidelines for maximum support spans.

Step-by-Step Guide to Pipe Support Span Calculation

Step 1: Gather Essential Data

Before starting the calculation, collect the following data:

- Pipe material and specifications (diameter, wall thickness)
- Pipe length and layout
- Operating temperature and pressure
- Contents (fluid type, density, viscosity)
- Support type and location
- Environmental loading conditions

Step 2: Determine Pipe Weight

Calculate the pipe weight per unit length considering:

- Pipe material density
- Wall thickness
- Inner and outer diameters

The general formula:

$$\text{Pipe weight per unit length (kg/m)} = \left(\frac{\pi}{4}\right) \times (D_o^2 - D_i^2) \times \text{density}$$

Where:

- D_o = outer diameter
- D_i = inner diameter

Step 3: Include Content Weight

Add the weight of the fluid or contents inside the pipe:

`Content weight per unit length = fluid density  $\times$  cross-sectional area`

Step 4: Calculate Total Load

Total load per unit length:

`Total load = Pipe weight + Content weight + External loads (if any)`

Step 5: Refer to Design Standards and Tables

Consult relevant standards for maximum allowable spans based on pipe size, material, and support type. For example, ASME B31.3 provides tables and guidelines that specify maximum spans for various pipe sizes and materials.

Step 6: Perform Structural Analysis (if needed)

For complex systems or unusual conditions, perform a structural analysis considering:

- Bending moments
- Deflections
- Support reactions

Software tools or manual calculations involving beam theory can help determine the maximum allowable span.

Step 7: Determine Support Spans

Using the data and standards, select support spacing that:

- Does not exceed the maximum span suggested
- Accounts for additional loads such as thermal expansion or seismic activity
- Ensures deflections stay within acceptable limits (often $L/240$ or $L/180$, where L is the span length)

Supporting Data and Charts

Many manufacturers and standards organizations provide support span charts that give recommended maximum spans based on pipe diameter and material. These charts are valuable tools for quick reference and validation.

Example: Typical Support Spans for Carbon Steel Pipe (ASME B31.3)

| Pipe Diameter (inches) | Max Support Span (feet) |

|-----|-----|

| 1/2" | 3.0 |

| 1" | 4.0 |

| 2" | 6.0 |

| 4" | 8.0 |

| 6" | 10.0 |

Note: Always verify with the latest code and manufacturer data.

Practical Considerations in Support Span Design

- Thermal Expansion and Contraction

Pipes expand and contract with temperature changes. Supports should accommodate thermal movement without inducing excessive stress.

Solutions include:

- Sliding supports

- Expansion loops
 - Flexible hangers
-
- Vibration and External Loads

In environments with high vibration or external forces, supports must be robust enough to prevent pipe movement and fatigue.

- Accessibility and Maintenance

Support placement should facilitate inspection, maintenance, and repair activities.

- Support Material and Design

Supports should be made of durable materials compatible with pipe material and operating environment.

Common Support Types and Their Impact on Span Calculation

- Hangers: Suspend pipe from overhead; typically used for vertical support.
- Saddle Supports: Support pipes on horizontal surfaces; suitable for larger diameters.
- Clamps and Straps: Provide secondary support; often used in combination with other supports.
- Spring Supports: Allow for thermal movement; critical in long runs with temperature variations.

Each support type influences the maximum permissible span, with spring supports often allowing longer spans due to their flexibility.

Final Tips and Best Practices

- Always adhere to the latest standards and manufacturer recommendations.
- Perform detailed calculations for critical or long-span pipes.
- Consider the worst-case scenario, including maximum fluid density, pressure, and temperature.
- Incorporate allowances for thermal expansion, movement, and external forces.
- Use support spacing as a part of a comprehensive piping stress analysis.

Conclusion

Pipe support span calculation is a vital component of effective piping system design, balancing safety, functionality, and cost-efficiency. By systematically assessing pipe loads, material properties, environmental factors, and applicable standards, engineers can determine optimal support locations that ensure reliable operation over the system's lifespan. A thorough understanding of these principles not only helps prevent structural failures but also enhances the overall integrity of piping installations in diverse industrial applications.

Question What is the purpose of calculating pipe support span? Calculating pipe support span ensures the pipe's structural integrity, prevents excessive deflection, and maintains safety and functionality under various loads. **Answer** What factors influence the span calculation for pipe supports? Factors include pipe diameter, material, weight (including contents), support type, allowable deflection, and environmental conditions such as temperature and vibration. How do you determine the maximum span between pipe supports? The maximum span is determined based on pipe diameter, material strength, allowable deflection limits, and applicable codes or standards, often using formulas or manufacturer guidelines. Are there standard formulas for pipe span calculation? Yes, standard formulas exist based on beam theory, such as the simple span formula considering pipe weight and allowable deflection, often supplemented by code-specific tables. How does pipe material affect support span calculation? Different materials have varying strength and flexibility; for example, steel pipes typically allow longer spans than plastic pipes due to higher strength and stiffness. What role do support types play in span calculation? Support types (e.g., hangers, brackets, rollers) influence allowable spans because different supports provide varying levels of restraint and load distribution. How do temperature changes impact pipe support span calculations? Temperature variations cause thermal expansion or contraction, which can affect deflection limits; spans may need to be reduced or supports designed to accommodate movement. Are there industry standards or codes that provide guidelines for pipe support spans? Yes, standards such as ASME B31.1, B31.3, and relevant API codes specify guidelines and maximum spans for different pipe sizes, materials, and conditions. What tools or software are available for calculating pipe support spans? Various engineering software like CAESAR II, PIPE-FLO, and AutoPIPE offer modules for pipe stress analysis and span calculation, helping ensure compliance and safety.

Related keywords: pipe support span, pipe support design, pipe span calculation, pipe load analysis, support spacing, pipe engineering, structural support for pipes, piping system analysis, support placement, pipe stress analysis

Read the full article online: [PIPE SUPPORT SPAN CALCULATION](#)